

CONNECT TO A PROJECTOR

HP 4525S

BRAND NOTEBOOKS

1 - PLUG THE PROJECTOR CABLE INTO THE VIDEO PORT ON YOUR COMPUTER.



2- MAKE SURE **THE PROJECTOR AND THE NOTEBOOK IS TURNED ON.**



3- TO DUPLICATE THE DISPLAY

Press **WINDOWS Key + P**



4- SELECT THE **"DUPLICATE"** OPTION FROM THE DISPLAY CHOICES MENU



USING THE PROJECTOR & THE SOUND SYSTEM WITH A NOTEBOOK

1 - TURN ON THE PROJECTOR BY PRESSING THE **"ON"** BUTTON OF THE **"PROJECTOR REMOTE CONTROL"** WHICH IS PLACED NEAR THE BOARD



IMPORTANT

Make sure that Projector is in **Computer 1** mode. You can easily check it by pressing the **"Computer"** button on the remote control.

2- PLUG THE PROJECTOR CABLE INTO THE VIDEO PORT ON YOUR COMPUTER.

3 - TO USE THE SOUND SYSTEM **POWER ON THE SOUND** SYSTEM WHICH IS IN THE TEACHERS DESK.



IMPORTANT

Make sure that "The Sound System VCD-AUX mode" is in **VCD mode**

4 - TO GET THE SOUND FROM SOUND SYSTEM **PLUG THE SOUND CABLE** WHICH IS ON THE TEACHERS DESK TO YOUR NOTEBOOK'S SOUND INPUT.



SOUND INPUT



SOUND CABLE